


Wood Parquet Dance Floor Layout Guide and Assembly Tips

Dance Floor
Designed
For Indoor
Use Only!



Dance Floor
Designed
For Indoor
Use Only!

M = Male

SETUP:

Start at UPPER LEFT 1st Row 1st Piece with Male facing to the bottom and right, work to right until completing first row then . . .
Move to 2nd Row 1st Piece and work to right until second row is completed then . . .
Move to 3rd Row 1st Piece and work to right until finishing third row and continuing on until floor size desired is completed.
Once finished assembling dance floor panels - attach edging pieces - Again starting at the upper left corner.

SETUP TIPS:

•Watch closely that Male (M) locations match diagram. •Attach each piece of paneling to previous panel by using set screw. •Be sure each panel is locked in place to previous panel by turning set screw completely into adjoining piece(s) DO NOT OVERTIGHTEN! •When finished be sure that all set screws are flush with dance floor surface.

TAKEDOWN:

Remove edging first then disassemble dance floor panel by panel. Once panel is disconnected from the next piece of panel run lock screw back flush into panel(DO NOT OVERTIGHTEN! (This helps to preserve floor while transporting).

MATERIALS LIST


of Pieces

3' x 3' Dance Floor Panels - _____

Corner Edging:

 Right Female Corner - 2

 Left Female Corner - 2

 Right Male Corner - 2

 Left Male Corner - 2

Straight Edging:

 Female - _____

 Male - _____

T Wrench(s) for Floor Locks - _____

Thank you for renting from  Herriott's
Rents • Tents • Events
2100 S Neil • Champaign 217/356-9713