


Instructions for Using a 5 Foot Charcoal Grill rented from *Herriott's*

Getting Started:

1. Screw the 4 legs into the 4 sockets located on the bottom of the firebox.
2. Stand grill upright on legs and place on a level area clear of combustible items.
3. To HELP with cooking, line firebox with tin foil to aid in reflecting heat from charcoal to cooking surface AND also makes clean-up much easier.




IMPORTANT!

4.  Place 15-20 lbs. of charcoal briquettes in two or three piles in firebox. (Enough to create a maximum 1-2 layer thickness when spread out over the surface of firebox.) Ignite charcoal briquette piles following briquette and charcoal fluid manufacturers instructions.

Cooking:

1. When coals are ready (usually 30-40 minutes after start-up), spread coals out evenly over the surface of the firebox.
2. Prior to putting grill top on firebox spray or wipe grill-top with a cooking oil to prevent food from sticking to cooking surface.
3. Place grill top on firebox at desired height. Begin cooking.



E-Z Cleanup:

Grill-Top

1. When finished cooking, remove grill-top and scrape free of food and cooking residue.
2. When grill-top has **COOLED**, wipe off with soap and water. Rinse.

Fire Box

3. **NEVER** pour water on hot coals to extinguish fire - this will warp the firebox. When all the coals are cool empty tin foil and ashes and dispose in an approved manner.

IMPORTANT!

Thank you for renting from

Herriott's
Rents • Tents • Events

2100 S Neil • Champaign 217/356-9713